

Session Border Controllers (SBC)

AudioCodes Mediant™ Series

Interoperability Lab

Configuration Note

Genesys Contact Center & Colt SIP Trunk using AudioCodes Mediant SBC



colt
smarter / faster / further



 Genesys

June 2014

Document # LTRT-12310

 **AudioCodes**

Table of Contents

1	Introduction	7
1.1	Intended Audience	7
1.2	About AudioCodes SBC Product Series	7
1.3	About Genesys Contact Center	7
2	Component Information.....	9
2.1	AudioCodes SBC Version.....	9
2.2	Colt SIP Trunking Version	9
2.3	Genesys Contact Center Version	9
2.4	Interoperability Test Topology	10
2.4.1	Environment Setup	12
2.4.2	Known Limitations/Restrictions.....	12
3	Configuring AudioCodes SBC	13
3.1	Step 1: Configure IP Network Interfaces.....	14
3.1.1	Step 1a: Configure VLANs.....	15
3.1.2	Step 1b: Configure Network Interfaces.....	15
3.1.3	Step 1c: Configure the Native VLAN ID.....	17
3.2	Step 2: Enable the SBC Application	17
3.3	Step 3: Configure Signaling Routing Domains	18
3.3.1	Step 3a: Configure Media Realms.....	18
3.3.2	Step 3b: Configure SRDs	20
3.3.3	Step 3c: Configure SIP Signaling Interfaces	21
3.4	Step 4: Configure Proxy Sets	23
3.5	Step 5: Configure IP Groups.....	26
3.6	Step 6: Configure IP Profiles	31
3.7	Step 7: Configure Coders	36
3.8	Step 8: Configure IP-to-IP Call Routing Rules	37
3.9	Step 9: Configure IP-to-IP Manipulation Rules.....	43
3.10	Step 10: Remote Agents	46
3.10.1	Step 10a: Configure Media Realm for Remote Agent	46
3.10.2	Step 10b: Configure SRD for Remote Agent.....	47
3.10.3	Step 10c: Configure SIP Signaling Interfaces for Remote Agent.....	48
3.10.4	Step 10d: Configure Remote (User) Agents IP Group	49
3.10.5	Step 10e: Configure IP Profiles for Remote Agents	51
3.10.6	Step 10f: Configure Classification Table for Remote Agents	53
3.10.7	Step 10g: Configure IP-to-IP Call Routing Rules for Remote (User) Agent.....	55
3.11	Step 11: Reset the SBC	60
A	AudioCodes <i>ini</i> File.....	61

This page is intentionally left blank

Notice

This Note shows how to connect a Genesys Contact Center and Colt SIP Trunk using AudioCodes Mediant SBC product series.

Information contained in this document is believed to be accurate and reliable at the time of printing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of printed material after the Date Published, nor can it accept responsibility for errors or omissions. Updates to this document and other documents as well as software files can be viewed by registered customers at <http://www.audiocodes.com/downloads>.

© Copyright 2014 AudioCodes Ltd. All rights reserved.

This document is subject to change without notice.

Date Published: June-24-2014

Trademarks

AudioCodes, AC, AudioCoded, Ardito, CTI2, CTI², CTI Squared, HD VoIP, HD VoIP Sounds Better, InTouch, IPmedia, Mediant, MediaPack, NetCoder, Netrake, Nuera, Open Solutions Network, OSN, Stretto, TrunkPack, VMAS, VoicePacketizer, VoIPerfect, VoIPerfectHD, What's Inside Matters, Your Gateway To VoIP and 3GX are trademarks or registered trademarks of AudioCodes Limited. All other products or trademarks are property of their respective owners. Product specifications are subject to change without notice.

WEEE EU Directive

Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

Customer Support

Customer technical support and services are provided by AudioCodes or by an authorized AudioCodes Service Partner. For more information on how to buy technical support for AudioCodes products and for contact information, please visit our Web site at www.audiocodes.com/support.

Documentation Feedback

AudioCodes continually strives to produce high quality documentation. If you have any comments (suggestions or errors) regarding this document, please fill out the Documentation Feedback form on our Web site at <http://www.audiocodes.com/downloads>.

This page is intentionally left blank

1 Introduction

This document shows how to configure AudioCodes' Session Border Controller (hereafter referred to as SBC) for interworking between Colt's SIP Trunk and Genesys Contact Center.



Note: Throughout this document, the term 'SBC' also refers to AudioCodes' Mediant E-SBC product series.

1.1 Intended Audience

The document is intended for engineers, or AudioCodes and Genesys Contact Center Partners who are responsible for installing and configuring Colt's SIP Trunk and Genesys Contact Center for enabling VoIP calls using AudioCodes' SBC.

1.2 About AudioCodes SBC Product Series

AudioCodes' family of SBC devices enables reliable connectivity and security between the enterprise and the Service Provider's VoIP networks.

The SBC provides perimeter defense as a way of protecting enterprises from malicious VoIP attacks; mediation for allowing the connection of any PBX and/or IP PBX to any Service Provider; and Service Assurance for service quality and manageability.

Designed as a cost-effective appliance, the SBC is based on field-proven VoIP and network services with a native host processor, allowing the creation of purpose-built multiservice appliances, providing smooth connectivity to cloud services, with integrated quality of service, SLA monitoring, security and manageability.

The native implementation of SBC provides a host of additional capabilities that are not possible with standalone SBC appliances such as VoIP mediation, PSTN access survivability, and third-party value-added services applications. This enables enterprises to utilize the advantages of converged networks and eliminate the need for standalone appliances.

AudioCodes' SBC is available as an integrated solution running on top of its field-proven Mediant Media Gateway and Multi-Service Business Router (MSBR) platforms, or as a software-only solution for deployment with third-party hardware.

1.3 About Genesys Contact Center

Genesys Contact Center Solutions allow companies to manage customer requirements effectively by routing customers to appropriate resources and agents through IVR and consolidated cross-channel management of all of a customer's interactions. Sophisticated profiling, outbound voice and performance management enables companies to provide very personalized customer care and delivery.

This page is intentionally left blank

2 Component Information

2.1 AudioCodes SBC Version

Table 2-1: AudioCodes SBC Version

SBC Vendor	AudioCodes
Models	<ul style="list-style-type: none"> ▪ Mediant 500 E-SBC ▪ Mediant 800 Gateway & E-SBC ▪ Mediant 1000B Gateway & E-SBC ▪ Mediant 2600 E-SBC ▪ Mediant 3000 Gateway & E-SBC ▪ Mediant 4000 SBC ▪ Mediant 9000 SBC ▪ Mediant Software SBC (Server Edition and Virtual Edition)
Software Version	SIP_ 6.80A.218.002
Protocol	<ul style="list-style-type: none"> ▪ SIP/UDP (to the Colt SIP Trunk) ▪ SIP/UDP, TCP or TLS (to the Genesys Contact Center system)
Additional Notes	None

2.2 Colt SIP Trunking Version

Table 2-2: Colt Version

Vendor/Service Provider	Colt
SSW Model/Service	Sonus
Software Version	8.4.4
Protocol	SIP
Additional Notes	None

2.3 Genesys Contact Center Version

Table 2-3: Genesys Contact Center Version

Vendor	Genesys
Software Version	Genesys SIP Server v8.1.1/Genesys Voice Platform (GVP) v8.5
Protocol	SIP
Additional Notes	None

2.4 Interoperability Test Topology

The Genesys Contact Center SIP Server is connected to the Colt ITSP SIP Trunk Provider via an SBC in similar way to an IP-PBX.




Note: Contact your Genesys Contact Center support channel for more information about topological scenarios.

Interoperability testing between AudioCodes SBC and Colt SIP Trunk with Genesys Contact Center 8.1 was performed using the following topology:

- The Enterprise is deployed with a Genesys Contact Center as a service using robust contact center functionality and interactive voice response (IVR) to efficiently connect customers with the right agents and information at the right time.
- The Enterprise is connected the Genesys Contact Center system to the PSTN network using Colt's SIP Trunking service (Internet Telephony Service Provider / ITSP).
- The Colt SIP Trunk connected to the enterprise using the public external network.
- The AudioCodes' SBC is deployed to interconnect between the Genesys Contact Center and the SIP trunk.
 - The SBC is connected to the Genesys Contact Center SIP Server on the Genesys Contact Center internal network, and to the Colt SIP Trunk located on the public network.
 - RTP from/to Colt SIP trunk flows via an SBC to/from Genesys Contact Center Media Server or to a local agent phone on the Call Center network or to a remote agent on the PSTN network or public Internet space.

The figure below illustrates the interoperability test topology:

Figure 2-1: Interoperability Test Topology



2.4.1 Environment Setup

The interoperability test topology includes the following environment setup:

Table 2-4: Environment Setup

Area	Setup
Network	<ul style="list-style-type: none"> Genesys Contact Center environment as a service is located on the Genesys Contact Center network Genesys Contact Center agent DN's (SIP phones) are located on the enterprise's LAN. Remote agent DN's are located in the public network Colt SIP Trunk is located on the WAN
Signaling Transcoding	<ul style="list-style-type: none"> Genesys Contact Center operates with SIP-over-UDP, TCP or TLS transport type Colt SIP Trunk operates with SIP-over-UDP transport type
Codecs Transcoding	<ul style="list-style-type: none"> Genesys Contact Center supports G.729, G.711A-law, G.711U-law, G.723 and G722.2 and G.726 coders Colt SIP Trunk supports G.729, G.711A-law, and G.726 coders
Media Transcoding	<ul style="list-style-type: none"> Genesys Contact Center and Colt SIP Trunk operate with RTP
DTMF	<ul style="list-style-type: none"> Genesys Contact Center supports delivering DTMF using SIP INFO message, RFC 2833 Named Telephony events, and in-band per ITU-T Recommendation Q.23 Colt supports only RFC 2833



Note: The configuration data used in this document, such as IP addresses and FQDNs are used for example purposes only. This data should be configured according to the site specifications.

2.4.2 Known Limitations/Restrictions

The following Genesys Call Center functionality is not supported by Colt SIP Trunk:

- SIP 302 Temporarily Moved. Colt ACKs the SIP 302, however does not re-route the call into the external network. This scenario can be mitigated by handling the SIP 302 locally on the SBC.
- SIP Authentication for outbound calls. Colt does not support challenging the SIP User Agent on receiving a SIP Request (outbound from the Contact Center).
- SIP Authentication for inbound calls. Colt does not support challenge/authentication for outbound calls from Colt (inbound to the Contact Center).

3 Configuring AudioCodes SBC

This section shows how to configure AudioCodes SBC for interworking between Genesys Contact Center and the Colt SIP Trunk. The configuration is based on the interoperability test topology described in Section 2.4 on page 10 and includes the following:

- SBC WAN interface - Colt SIP Trunking environment
- SBC LAN interface - Genesys Contact Center environment

Configuration is performed using the SBC's embedded Web server (hereafter referred to as *Web interface*).


Notes:

- To implement the Genesys Contact Center and Colt SIP Trunk based on the configuration described in this section, the SBC must be installed with a Software License Key that includes the following software features:

- ✓ SBC
- ✓ Security
- ✓ RTP
- ✓ SIP

For more information about the Software License Key, contact your AudioCodes Sales Representative.

- The scope of this interoperability test and document does not cover all security aspects of connecting the SIP Trunk to the Genesys Contact Center environment. Comprehensive security measures should be implemented per the enterprise's security policies. For security recommendations on AudioCodes' products, refer to the *Recommended Security Guidelines* document.
- Before you begin configuring the SBC, ensure that the SBC's Web interface navigation tree is in **Advanced** display mode, selectable as shown below:




Note that when the SBC is reset, the navigation tree reverts to **Basic** display mode.

3.1 Step 1: Configure IP Network Interfaces

This step shows how to configure the SBC's IP network interfaces. A number of methods can be used to deploy the SBC; the interoperability test topology uses the following method:

- SBC interfaces with these IP entities:
 - Genesys Contact Center, located on the Genesys Contact Center Service Provider network (LAN)
 - Colt SIP Trunk, located on the WAN
- SBC connects to the WAN through a DMZ network.
- Physical connection to the LAN: Type depends on the method used to connect to the Genesys Contact Center Service Provider's network. In the interoperability test topology, the SBC connects to the LAN and WAN using dedicated LAN ports (i.e., using two ports and two network cables).
- SBC also uses two logical network interfaces:
 - LAN (VLAN ID 1)
 - WAN (VLAN ID 2)

Figure 3-1: Network Interfaces in Interoperability Test Topology



3.1.1 Step 1a: Configure VLANs

This step shows how to define VLANs for each of the following interfaces:

- LAN VoIP (assigned the name "Call Center")
- WAN VoIP (assigned the name "Provider")

➤ **To configure the VLANs:**

1. Open the Ethernet Device Table page (**Configuration** tab > **VoIP** menu > **Network** > **Ethernet Device Table**); in the table you'll see an existing row for VLAN ID 1 and underlying interface GROUP_1.
2. Add another VLAN ID 2 for the WAN side as follows:

Parameter	Value
Index	1
VLAN ID	2
Underlying Interface	GROUP_2 (Ethernet port group)
Name	GROUP_2

Figure 3-2: Configured VLAN IDs in Ethernet Device Table

Ethernet Device Table			
Add +		Edit ✎	Delete 🗑
		Show/Hide 📄	
Index	VLAN ID	Underlying Interface	Name
0	1	GROUP_1	GROUP_1
1	2	GROUP_2	GROUP_2

3.1.2 Step 1b: Configure Network Interfaces

This step shows how to configure the following interfaces:

- LAN VoIP interface (assigned the name "Trusted")
- and-
- WAN VoIP interface (assigned the name "Untrusted")

➤ **To configure these IP network interfaces:**

1. Open the IP Interfaces Table page (**Configuration** tab > **VoIP** menu > **Network** > **IP Interfaces Table**).
2. Modify the existing LAN network interface:
 - a. Select the **Index** option of the **OAMP + Media + Control** table row, and then click **Edit**.
 - b. Configure the interface as follows:

Parameter	Value
IP Address	192.168.20.200 (IP address of SBC)
Prefix Length	24 (subnet mask in bits for 255.255.255.0)
Gateway	192.168.20.1

Parameter	Value
VLAN ID	1
Interface Name	Trusted (arbitrary descriptive name)
Primary DNS Server IP Address	Add DNS Server IP address in this network
Underlying Device	GROUP_1

3. Add a network interface for the WAN side:

- a.** Enter **1**, and then click **Add Index**.
- b.** Configure the interface as follows:

Parameter	Value
Application Type	Media + Control
IP Address	203.0.113.120 (WAN IP address)
Prefix Length	26 (for 255.255.255.128)
Gateway	203.0.113.65 (router's IP address)
VLAN ID	2
Interface Name	Untrusted
Primary DNS Server IP Address	8.8.4.4 (as specified by ISP)
Secondary DNS Server IP Address	8.8.8.8 (as specified by ISP)
Underlying Device	GROUP_2

4. Click **Apply**, and then **Done**.

The configured IP network interfaces are shown below:

Figure 3-3: Configured Network Interfaces in IP Interfaces Table

▼ Interface Table									
Add + Edit Edit Delete									Show/Hide
Index	Application Type	Interface Mode	IP Address	Prefix Length	Default Gateway	Interface Name	Primary DNS	Secondary DNS	Underlying Device
0	OAMP + Media + Control	IPv4 Manua	192.168.20.200	24	192.168.20.1	Trusted	0.0.0.0	0.0.0.0	GROUP_1
1	Media + Control	IPv4 Manua	203.0.113.120	26	203.0.113.65	Untrusted	8.8.4.4	8.8.8.8	GROUP_2

3.1.3 Step 1c: Configure the Native VLAN ID

This step shows how to configure the Native VLAN ID for the LAN and WAN interfaces.

➤ **To configure the Native VLAN ID for the IP network interfaces:**

1. Open the Physical Ports Settings page (**Configuration** tab > **VoIP** menu > **Network** > **Physical Ports Table**).
2. For the **GROUP_1** member ports, set the 'Native Vlan' field to **1**. This VLAN is assigned to network interface "Call Center" and is the trusted interface.
3. For the **GROUP_2** member ports, set the 'Native Vlan' field to **2**. This VLAN is assigned to network interface "Provider" and is the untrusted interface.

Figure 3-4: Configured Port Native VLAN



Index	Port	Mode	Native Vlan	Speed&Duplex	Description	Group Member	Group Status
0	GE_1	Enable	1	Auto Negotiation	Trusted	GROUP_1	Active
1	GE_2	Enable	2	Auto Negotiation	Untrusted	GROUP_2	Active


3.2 Step 2: Enable the SBC Application

This step shows how to enable the SBC application.

➤ **To enable the SBC application:**

1. Open the Applications Enabling page (**Configuration** tab > **VoIP** menu > **Applications Enabling** > **Applications Enabling**).

Figure 3-5: Enabling SBC Application



⚡ SBC Application
Enable ▼

2. From the 'SBC Application' drop-down list, select **Enable**.
3. Click **Submit**.
4. Reset the SBC with a burn to flash for the setting to take effect (see Section 3.11 on page 60).

3.3 Step 3: Configure Signaling Routing Domains

This step shows how to configure Signaling Routing Domains (SRDs). The SRD represents a logical VoIP network. Each logical or physical connection requires an SRD, for example, if the SBC interfaces with both the LAN and WAN, a different SRD is required for each such connection.

The SRD comprises the following:

- **Media Realm:** defines a UDP port range for RTP/SRTP (media) traffic on a specific logical IP network interface of the SBC.
- **SIP Interface:** defines a listening port and type (UDP, TCP, or TLS) for SIP signaling traffic on a specific logical IP network interface of the SBC.

3.3.1 Step 3a: Configure Media Realms

This step shows how to configure Media Realms. The simplest way is to create two Media Realms - one for internal (LAN) traffic and one for external (WAN) traffic.

➤ **To configure Media Realms:**

1. Open the Media Realm Table page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **Media Realm Table**).
2. Modify the existing Media Realm for LAN traffic:

Parameter	Value
Index	1
Media Realm Name	MR-SBC2Genesys (descriptive name)
IPv4 Interface Name	Trusted
Port Range Start	6000 (represents lowest UDP port number used for media on LAN)
Number of Media Session Legs	100 (media sessions assigned with port range)

Figure 3-6: Configuring Media Realm for LAN

Edit Record #1

Index	1
Media Realm Name	MR1-SBC2Genesys
IPv4 Interface Name	Trusted
IPv6 Interface Name	None
Port Range Start	6000
Number Of Media Session Legs	100
Port Range End	6990
Default Media Realm	Yes
QoE Profile	None
BW Profile	None

Submit
Cancel

3. Configure a Media Realm for WAN traffic:

Parameter	Value
Index	2
Media Realm Name	MR2-SBC2Colt (arbitrary name)
IPv4 Interface Name	Provider
Port Range Start	8000 (represents lowest UDP port number used for media on WAN)
Number of Media Session Legs	100 (media sessions assigned with port range)

Figure 3-7: Configuring Media Realm for WAN

Edit Record #2

Index	<input type="text" value="2"/>
Media Realm Name	<input type="text" value="MR2-SBC2Colt"/>
IPv4 Interface Name	<input type="text" value="Untrusted"/>
IPv6 Interface Name	<input type="text" value="None"/>
Port Range Start	<input type="text" value="8000"/>
Number Of Media Session Legs	<input type="text" value="100"/>
Port Range End	<input type="text" value="8990"/>
Default Media Realm	<input type="text" value="No"/>
QoE Profile	<input type="text" value="None"/>
BW Profile	<input type="text" value="None"/>

The configured Media Realms are shown in the figure below:

Figure 3-8: Configured Media Realms in Media Realm Table

Media Realm Table			
Add +			
Index	Media Realm Name	IPv4 Interface Name	IPv6 Interface Name
1	MR1-SBC2Genesys	Trusted	None
2	MR2-SBC2Colt	Untrusted	None

3.3.2 Step 3b: Configure SRDs


This step shows how to configure SRDs. For the interoperability test topology, an SRD for the SBC's internal (toward Genesys Contact Center) and external interfaces (toward the Colt SIP Trunk) are defined.

➤ **To configure SRDs:**

1. Open the SRD Settings page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **SRD Table**).
2. Configure an SRD for the SBC's internal interface (toward Genesys Contact Center):

Parameter	Value
SRD Index	1
SRD Name	SRD1-Genesys (descriptive name for SRD)
Media Realm	MR1-SBC2Genesys (associates SRD with Media Realm)

Figure 3-9: Configuring LAN SRD



Edit Record #1	
Index	1
Name	SRD1-Genesys
Media Realm Name	MR1-SBC2Genesys
Media Anchoring	Enable
Block Unregistered Users	NO
Max. Number of Registered Users	-1
Enable Un-Authenticated Registrations	Enable
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

3. Configure an SRD for the SBC's external interface (toward the Colt SIP Trunk):

Parameter	Value
SRD Index	2
SRD Name	SRD2-Colt
Media Realm	MR2-SBC2Colt

Figure 3-10: Configuring WAN SRD

Edit Record #2	
Index	2
Name	SRD2-Colt
Media Realm Name	MR2-SBC2Colt
Media Anchoring	Enable
Block Unregistered Users	NO
Max. Number of Registered Users	-1
Enable Un-Authenticated Registrations	Enable
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

3.3.3 Step 3c: Configure SIP Signaling Interfaces

This step shows how to configure SIP Interfaces. For the interoperability test topology, an internal and external SIP Interface is configured for the SBC.

➤ **To configure SIP Interfaces:**

1. Open the SIP Interface Table page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **SIP Interface Table**).
2. Configure a SIP interface for the LAN:

Parameter	Value
Index	1
Interface Name	Genesys (arbitrary descriptive name)
Network Interface	Trusted
Application Type	SBC
TCP and UDP	5060
TLS Port	5061
SRD	1

3. Configure a SIP interface for the WAN:

Parameter	Value
Index	2
Interface Name	Colt (arbitrary descriptive name)
Network Interface	Untrusted
Application Type	SBC
TCP and UDP	5060
SRD	2

The configured SIP Interfaces are shown in the figure below:

Figure 3-11: Configured SIP Interfaces in SIP Interface Table

SIP Interface Table							
Add +		Edit ✎		Delete 🗑		Show/Hide 📄	
Index ↕	SIP Interface Name	Network Interface	Application Type	UDP Port	TCP Port	TLS Port	SRD
1	Genesys	Trusted	SBC	5060	5060	5061	1
2	Colt	Untrusted	SBC	5060	5060	5061	2

3.4 Step 4: Configure Proxy Sets

This step shows how to configure Proxy Sets. The Proxy Set defines the destination address (IP address or FQDN) of the IP entity server. Proxy Sets can also be used to configure load balancing between multiple servers.

For the interoperability test topology, two Proxy Sets need to be configured for the following IP entities:

- Genesys Contact Center SIP Server
- Colt SIP Trunk

These Proxy Sets will later be associated with IP Groups.

➤ To configure Proxy Sets:

1. Open the Proxy Sets Table page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **Proxy Sets Table**).
2. Configure a Proxy Set for the Genesys Contact Center:

Parameter	Value
Proxy Set ID	1
Proxy Address	sipserver.genesys-domain.com:5060 Genesys Contact Center IP address / FQDN and destination port For UDP and TCP, the port is 5060 . If TLS is used, the port must be 5061 .
Transport Type	UDP, TCP or TLS depends on the configuration of Genesys Contact Center Transport Type (Default is UDP)
Proxy Name	Genesys SIP Server (arbitrary descriptive name)
Enable Proxy Keep Alive	Using Options
SRD Index	1

Figure 3-12: Configuring Proxy Set for Genesys Contact Center SIP Server

Proxy Set ID

1

	Proxy Address	Transport Type
1	sipserver.genesys-iot.com:5060	
2		
3		
4		
5		
6		
7		
8		
9		
10		

Proxy Name

Genesys SIP Server

Enable Proxy Keep Alive

Using Options

Proxy Keep Alive Time

60

Proxy Load Balancing Method

Disable

Is Proxy Hot Swap

No

Proxy Redundancy Mode

Not Configured

SRD Index

1

Classification Input

IP only

3. Configure a Proxy Set for the Colt SIP Trunk:

Parameter	Value
Proxy Set ID	2
Proxy Address	gw0.colts-iot.com:5060 (Colt (example) IP address / FQDN and destination port)
Transport Type	UDP
Proxy Name	Colt (arbitrary descriptive name)
Enable Proxy Keep Alive	Using Options
SRD Index	2 (enables classification by Proxy Set for SRD of IP Group belonging to Colt SIP Trunk)

Figure 3-13: Configuring Proxy Set for Colt SIP Trunk

Proxy Set ID		2
--------------	--	---

	Proxy Address	Transport Type
1	gw0.coltsip.com:5060	
2		
3		
4		
5		
6		
7		
8		
9		
10		

Proxy Name		Colt
Enable Proxy Keep Alive		Using Options
Proxy Keep Alive Time		60
Proxy Load Balancing Method		Disable
Is Proxy Hot Swap		No
Proxy Redundancy Mode		Not Configured
SRD Index		2
Classification Input		IP only

3.5 Step 5: Configure IP Groups

This step shows how to configure IP Groups. The IP Group represents an IP entity on the network with which the SBC communicates. This can be a server (e.g., IP PBX or ITSP) or it can be a group of users (e.g., LAN IP phones). For servers, the IP Group is typically used to define the server's IP address by associating it with a Proxy Set. A typical deployment consists of multiple IP Groups associated with the same SRD. For example, you can have two LAN IP PBXs sharing the same SRD, and two ITSPs / SIP Trunks sharing the same SRD. Once IP Groups are configured, they are used to configure IP-to-IP routing rules for denoting the source and destination of the call.

In the interoperability test topology, IP Groups were configured for the following IP entities:

- Genesys Contact Center located on LAN (Server Group)
- Colt SIP Trunk located on WAN (Server Group)
- Remote User Agents located in the WAN (User Group) (see Section 3.10 on page 46)

➤ To configure IP Groups:

1. Open the IP Group Table page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **IP Group Table**).
2. Configure an IP Group for the Genesys Contact Center SIP Server:

Parameter	Value
Index	1
Type	Server
Description	IPG1-SBC2Genesys (arbitrary descriptive name)
Proxy Set ID	1
SIP Group Name	sipserver.genesys-iot.com (according to ITSP requirement)
SRD	1
Media Realm Name	MR1-SBC2Genesys
IP Profile ID	1
Local Host Name	192.168.20.200

Figure 3-14: Configuring an IP Group for the Genesys Call Center (Common Tab)

Common		SBC
Index	1	
Type	Server	
Description	IPG1-SBC2Genesys	
Proxy Set ID	1	
SIP Group Name	sipserver.genesys-iot.com	
Contact User		
SRD	1	
Media Realm Name	MR1-SBC2Genesys	
IP Profile ID	1	
Local Host Name	192.168.20.200	
UUI Format	Disable	
QoE Profile	None	
Bandwidth Profile	None	
Media Enhancement Profile	None	
Always Use Source Address	No	
<div>Submit Cancel</div>		

Figure 3-15: Configuring an IP Group for the Genesys Call Center (SBC Tab)

Common SBC	
Index	1
Classify By Proxy Set	Enable
Max. Number of Registered Users	-1
Inbound Message Manipulation Set	-1
Outbound Message Manipulation Set	-1
Registration Mode	User Initiates Registrat
Authentication Mode	User Authenticates
Authentication Method List	
SBC Client Forking Mode	Sequential
Source URI Input	
Destination URI Input	
Username	
Password	
Msg Man User Defined String1	
Msg Man User Defined String2	
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

3. Configure an IP Group for the Colt SIP Trunk:

Parameter	Value
Index	2
Type	Server
Description	IPG2-SBC2Colt (arbitrary descriptive name)
Proxy Set ID	2
SIP Group Name	217.110.230.98 (according to ITSP requirement)
SRD	2
Media Realm Name	MR2-SBC2Colt
IP Profile ID	2
Local Host Name	208.0.113.120

Figure 3-16: Configuring an IP Group for the Colt SIP Trunk (Common Tab)

Common	SBC
Index	2
Type	Server
Description	IPG2-SBC2Colt
Proxy Set ID	2
SIP Group Name	gw0.colt-iot.com
Contact User	
SRD	2
Media Realm Name	MR2-SBC2Colt
IP Profile ID	2
Local Host Name	
UUI Format	Disable
QoE Profile	None
Bandwidth Profile	None
Media Enhancement Profile	None
Always Use Source Address	No
<input type="button" value="✓ Submit"/> <input type="button" value="✕ Cancel"/>	

Figure 3-17: Configuring an IP Group for the Colt SIP Trunk (SBC Tab)

Common		SBC
Index	2	
Classify By Proxy Set	Enable	
Max. Number of Registered Users	-1	
Inbound Message Manipulation Set	-1	
Outbound Message Manipulation Set	-1	
Registration Mode	User Initiates Registrat	
Authentication Mode	User Authenticates	
Authentication Method List		
SBC Client Forking Mode	Sequential	
Source URI Input		
Destination URI Input		
Username		
Password		
Msg Man User Defined String1		
Msg Man User Defined String2		
		<input type="button" value="Submit"/> <input type="button" value="Cancel"/>

The configured IP Groups are shown in the figure below:

Figure 3-18: Configured IP Groups in IP Group Table

IP Group Table					
Add +					
Index	Type	Description	Proxy Set ID	SIP Group Name	Contact User
1	Server	IPG1-SBC2Genesys	1	sipserver.genesys-iot.com	
2	Server	IPG2-SBC2Colt	2	gw0.col-iot.com	

3.6 Step 6: Configure IP Profiles

This step describes how to configure IP Profiles. In this interoperability test topology, the IP Profile defines a set of call capabilities relating to signaling (e.g., SIP message terminations such as REFER) and media (e.g., coder and transcoding method).

In this interoperability test topology, IP Profiles were configured for the following IP entities:

- Genesys Contact Center
- Colt SIP trunk



Note: The IP Profile index values were assigned to the IP Groups in the previous step (see Section 3.5 3.5 on page 26).

➤ **To configure IP Profiles:**

1. Open the IP Profile Settings page (**Configuration** tab > **VoIP** > **Coders and Profiles** > **IP Profile Settings**).
2. Click **Add**.
3. Click the **Common** tab, and then configure the parameters as follows:

Parameter	Value
Index	1
Profile Name	Genesys SIP Server (arbitrary descriptive name)

Figure 3-19: Configuring IP Profile for Genesys Contact Center (Common Tab)

Parameter	Value
Index	1
Profile Name	Genesys SIP Server
RTP IP DiffServ	46
Signaling DiffServ	40
RTP Redundancy Depth	0
Disconnect on Broken Connection	Yes
Media IP Version Preference	Only IPv4
Symmetric MKI	Disable
MKI Size	0
Reset SRTP Upon Re-key	Disable
Generate SRTP keys mode	Only If Required

Submit Cancel



Note: Presently, no parameters require configuration on the **SBC** tab for the Genesys Contact Center IP Profile. All parameters are set to their default values. The IP Profile is created for the purpose of future configuration only.

Figure 3-20: Configuring IP Profile for Genesys Contact Center (SBC Tab)

Common		SBC
Index	1	
Extension Coders Group ID	None	
Transcoding Mode	Only If Required	
Allowed Media Types		
Allowed Coders Group ID	None	
Allowed Video Coders Group ID	None	
Allowed Coders Mode	Restriction	
SBC Media Security Behavior	As Is	
RFC 2833 Behavior	As Is	
Alternative DTMF Method	As Is	
P-Asserted-Identity	As Is	
Diversion Mode	As Is	
History-Info Mode	As Is	
Fax Coders Group ID	None	
Fax Behavior	As Is	
Fax Offer Mode	All coders	
Fax Answer Mode	Single coder	
PRACK Mode	Transparent	
Session Expires Mode	Transparent	
Remote Update Support	Supported	
Remote re-INVITE	Supported	
Remote Delayed Offer Support	Supported	
Remote REFER Behavior	Regular	
Remote 3xx Behavior	Transparent	
Remote Multiple 18x	Supported	
Remote Early Media Response Type	Transparent	
Remote Early Media	Supported	
Enforce MKI Size	Don't enforce	
Remote Early Media RTP Behavior	Immediate	
Remote RFC 3960 Gateway Model Support	Not Supported	
Remote Can Play Ringback	Yes	
RFC 2833 DTMF Payload Type	0	
User Registration Time	0	
Reliable Held Tone Source	Yes	
Play Held Tone	No	
Remote Hold Format	Transparent	
Remote Replaces Behavior	Transparent	
SDP Ptime Answer	Remote Answer	
Preferred PTime	0	
Use Silence Suppression	Transparent	
RTP Redundancy Behavior	AS IS	
Play RBT To Transferee	No	
RTCP Mode	Transparent	
Jitter Compensation	Disable	
Remote Renegotiate on Fax Detection	Don't Care	
		<input type="button" value="Submit"/> <input type="button" value="Cancel"/>

4. Configure an IP Profile for the Colt SIP Trunk:
 - a. Click **Add**.
 - b. Click the **Common** tab, and then configure the parameters as follows:

Parameter	Value
Index	2
Profile Name	Colt (arbitrary descriptive name)

Figure 3-21: Configuring IP Profile for Colt SIP Trunk (Common Tab)

Parameter	Value
Index	2
Profile Name	Colt
RTP IP DiffServ	46
Signaling DiffServ	40
RTP Redundancy Depth	0
Disconnect on Broken Connection	Yes
Media IP Version Preference	Only IPv4
Symmetric MKI	Disable
MKI Size	0
Reset SRTP Upon Re-key	Disable
Generate SRTP keys mode	Only If Required

- c. Click the **SBC** tab, and then configure the parameters as follows:

Parameter	Value
Media Security Behavior	'As Is'
Remote REFER Behavior	IP Group Name (To change the host name on the Refer-To header, to the ITSP host name)

Figure 3-22: Configuring IP Profile for Colt SIP Trunk – SBC Tab

Common		SBC
Index	2	
Extension Coders Group ID	None	
Transcoding Mode	Only If Required	
Allowed Media Types		
Allowed Coders Group ID	None	
Allowed Video Coders Group ID	None	
Allowed Coders Mode	Restriction	
SBC Media Security Behavior	As Is	
RFC 2833 Behavior	As Is	
Alternative DTMF Method	As Is	
P-Asserted-Identity	As Is	
Diversion Mode	As Is	
History-Info Mode	As Is	
Fax Coders Group ID	None	
Fax Behavior	As Is	
Fax Offer Mode	All coders	
Fax Answer Mode	Single coder	
PRACK Mode	Transparent	
Session Expires Mode	Transparent	
Remote Update Support	Supported	
Remote re-INVITE	Supported	
Remote Delayed Offer Support	Supported	
Remote REFER Behavior	IP Group Name	
Remote 3xx Behavior	Transparent	
Remote Multiple 18x	Supported	
Remote Early Media Response Type	Transparent	
Remote Early Media	Supported	
Enforce MKI Size	Don't enforce	
Remote Early Media RTP Behavior	Immediate	
Remote RFC 3960 Gateway Model Support	Not Supported	
Remote Can Play Ringback	Yes	
RFC 2833 DTMF Payload Type	0	
User Registration Time	0	
Reliable Held Tone Source	Yes	
Play Held Tone	No	
Remote Hold Format	Transparent	
Remote Replaces Behavior	Transparent	
SDP Ptime Answer	Remote Answer	
Preferred PTime	0	
Use Silence Suppression	Transparent	
RTP Redundancy Behavior	AS IS	
Play RBT To Transferee	No	
RTCP Mode	Transparent	
Jitter Compensation	Disable	
Remote Renegotiate on Fax Detection	Don't Care	
		<input checked="" type="button" value="Submit"/> <input type="button" value="Cancel"/>



Note: Colt does not support the re-routing of a call into the external (PSTN) network upon the receipt of a SIP 302 Moved Temporarily response. Consequently, the SBC transparently passes the 302 Moved Temporarily response from Genesys to Colt. This response is then ACK'd by the Colt ITSP; however, there is no subsequent routing of the call by Colt to the external DN. This issue is overcome by the SBC locally; the 302 Moved Temporarily response from the SIP Server is ACK'd by the SBC, and then the SBC sends a subsequent INVITE to the temporary external number via Colt. The call is then anchored by the SBC.

The 302 Moved Temporarily handling on the SBC is configured by setting SBCRemote3xxBehavior = 'handle locally' in the IP Profile for the Colt IP Group, and by setting an IP2IP route for calls originating from the Colt IP Group to trigger on 3xx/REFER and route to the Colt ITSP IP Group.

Note that when adding the trigger route, i.e. this scenario is a specific instance of the normal routing rule and should therefore precede it in the IP-to-IP Routing table, i.e. route "Colt2Genesys" later defined (see Section 3.8 on page 37).

The configured IP Groups are shown in the figure below:

Figure 3-23: Configured IP Profiles in IP Profile Table

IP Profile Settings	
<div> Add + Edit ✎ Delete 🗑️ </div> <div>Show/Hide 📄</div>	
Index ↕	Profile Name
1	Genesys SIP Server
2	Colt

3.7 Step 7: Configure Coders

The Colt SIP Trunk supports G.729, G.711A-law, and G.726 coders.

The Genesys Contact Center supports G.729, G.711A-law, G.711U-law, G.723 and GSM coders.

Since both entities have common codecs supported, no transcoding is needed; therefore no special SBC configuration is required.

However, if support is required in the deployment for G.711U-law or G.726 (not supported on either), an SBC transcoding configuration is required (refer to the *SBC User's Manual*) for Coder Transcoding configuration.



Note: The 'DSP channels' Feature Key and definition is required for activating Coder Transcoding.

3.8 Step 8: Configure IP-to-IP Call Routing Rules

This step shows how to configure IP-to-IP call routing rules. These rules define the routes for forwarding SIP messages (e.g., INVITE) received from one IP entity to another. The SBC selects the rule whose configured input characteristics (e.g., IP Group) match those of the incoming SIP message. If the input characteristics do not match the first rule in the table, they are compared to the second rule, and so on, until a matching rule is located. If no rule is matched, the message is rejected. The routing rules use the configured IP Groups to denote the source and destination of the call. As configured in Section 3.5 on page 25, IP Group 1 represents the Genesys Contact Center, and IP Group 2 represents the Colt SIP Trunk.

For the interoperability test topology, the following IP-to-IP routing rules are configured to route calls between Genesys Contact Center (LAN) and Colt SIP Trunk (WAN):


- Terminate SIP OPTIONS messages on the SBC that are received from the LAN
- Calls from Genesys Contact Center to Colt SIP Trunk
- Calls from Colt SIP Trunk to Genesys Contact Center

➤ **To configure IP-to-IP routing rules:**

1. Open the IP-to-IP Routing Table page (**Configuration** tab > **VoIP** menu > **SBC** > **Routing SBC** > **IP-to-IP Routing Table**).
2. Configure a rule to terminate SIP OPTIONS messages received from the LAN:
 - a. Click **Add**.
 - b. Click the **Rule** tab, and then configure the parameters as follows:

Parameter	Value
Index	0
Route Name	OPTIONS termination (arbitrary descriptive name)
Source IP Group ID	1
Request Type	OPTIONS
Destination Type	Dest Address
Destination Address	internal

Figure 3-24: Configuring IP-to-IP Routing Rule for Terminating SIP OPTIONS from LAN – Rule Tab



The screenshot shows the 'Rule' tab of a configuration window. The 'Rule' tab is selected, and the 'Action' tab is also visible. The configuration parameters are as follows:


Parameter	Value
Index	0
Route Name	OPTIONS termination
Source IP Group ID	1
Source Username Prefix	*
Source Host	*
Destination Username Prefix	*
Destination Host	*
Request Type	OPTIONS
Message Condition	None
ReRoute IP Group ID	-1
Call Trigger	Any

At the bottom right, there are 'Submit' and 'Cancel' buttons.

- Click the **Action** tab, and then configure the parameters as follows:

Parameter	Value
Destination Type	Dest Address
Destination Address	internal

Figure 3-25: Configuring IP-to-IP Routing Rule for Terminating SIP OPTIONS from LAN – Action Tab



The screenshot shows the 'Action' tab of the configuration window. The 'Rule' tab is also visible. The configuration parameters are as follows:

Parameter	Value
Index	0
Destination Type	Dest Address
Destination IP Group ID	-1
Destination SRD ID	None
Destination Address	internal
Destination Port	0
Destination Transport Type	
Alternative Route Options	Route Row
Group Policy	None
Cost Group	None
Rules Set Id	-1

At the bottom right, there are 'Submit' and 'Cancel' buttons.

4. Configure a rule to route calls from Genesys Contact Center to Colt SIP Trunk:
 - a. Click **Add**.
 - b. Click the **Rule** tab, and then configure the parameters as follows:

Parameter	Value
Index	1
Route Name	Genesys2Colt (arbitrary descriptive name)
Source IP Group ID	1


Figure 3-26: Configuring IP-to-IP Routing Rule for Genesys to Colt – Rule tab

Rule	Action
Index	1
Route Name	Genesys2Colt
Source IP Group ID	1
Source Username Prefix	*
Source Host	*
Destination Username Prefix	*
Destination Host	*
Request Type	All
Message Condition	None
ReRoute IP Group ID	-1
Call Trigger	Any
Call Setup Rules Set ID	-1
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

5. Click the **Action** tab, and then configure the parameters as follows:

Parameter	Value
Destination Type	IP Group
Destination IP Group ID	2
Destination SRD ID	2

Figure 3-27: Configuring IP-to-IP Routing Rule for Genesys to Colt – Action tab



Index	1
Destination Type	IP Group
Destination IP Group ID	2
Destination SRD ID	2
Destination Address	
Destination Port	0
Destination Transport Type	
Alternative Route Options	Route Row
Group Policy	None
Cost Group	None
Rules Set Id	-1

Submit Cancel

6. Configure a rule to route calls from Colt SIP Trunk to Genesys Contact Center:
 - a. Click **Add**.
 - b. Click the **Rule** tab, and then configure the parameters as follows:

Parameter	Value
Index	2
Route Name	Colt2Genesys (arbitrary descriptive name)
Source IP Group ID	2

Figure 3-28: Configuring IP-to-IP Routing Rule for Colt to Genesys – Rule tab

Rule	Action
Index	2
Route Name	Colt2Genesys
Source IP Group ID	2
Source Username Prefix	*
Source Host	*
Destination Username Prefix	*
Destination Host	*
Request Type	All
Message Condition	None
ReRoute IP Group ID	-1
Call Trigger	Any
Call Setup Rules Set ID	-1
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

7. Click the **Action** tab, and then configure the parameters as follows:

Parameter	Value
Destination Type	IP Group
Destination IP Group ID	1
Destination SRD ID	1

Figure 3-29: Configuring IP-to-IP Routing Rule for Colt to Genesys – Action tab

Rule	Action
Index	2
Destination Type	IP Group
Destination IP Group ID	1
Destination SRD ID	1
Destination Address	
Destination Port	0
Destination Transport Type	
Alternative Route Options	Route Row
Group Policy	None
Cost Group	None
Rules Set Id	-1
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

The configured routing rules are shown in the figure below:

Figure 3-30: Configured IP-to-IP Routing Rules in IP-to-IP Routing Table

▼ IP-to-IP Routing Table										
Add + Insert + Edit ✎ Delete 🗑 Up ↑ Down ↓ Show/Hide 📄										
Index ↕	Route Name	Source Host	Destination Username Prefix	Destination Host	Message Condition	ReRoute IP Group ID	Call Trigger	Call Setup Rules Set ID	Destination Type	Destination SRD ID
0	OPTIONS termination	*	*	*	None	-1	Any	-1	Dest Address	None
1	Genesys2Colt	*	*	*	None	-1	Any	-1	IP Group	2
2	Colt2Genesys	*	*	*	None	-1	Any	-1	IP Group	1



Note: The routing configuration may change according to your specific deployment topology.

For example, the deployment specification may indicate that OPTIONS termination should pass through the SBC to the far end, or, other criteria listed in the table may be used for determining routing.

3.9 Step 9: Configure IP-to-IP Manipulation Rules

This step shows how to configure IP-to-IP manipulation rules. These rules manipulate the source and / or destination number. The device supports SIP URI user part (source and destination) manipulations for inbound and outbound routing. The manipulation rules use the configured IP Groups to denote the source and destination of the call. As configured in Section 3.5 on page 25, IP Group 1 represents Genesys Contact Center, and IP Group 2 represents Colt SIP Trunk.



Note: The following manipulation rules are only examples. Adapt the manipulation table according to your environment dial plan.

For this interoperability test topology, a manipulation is configured to remove the first 3 digits from the destination number for calls from IP Group 2 (Colt SIP Trunk) to IP Group 1 (i.e., Genesys Contact Center) for any destination username prefix.

➤ **To configure a number manipulation rule:**

1. Open the IP-to-IP Outbound Manipulation page (**Configuration** tab > **VoIP** menu > **SBC** > **Manipulations SBC** > **IP-to-IP Outbound**).
2. Click **Add**.
3. Click the **Rule** tab, and then configure the parameters as follows:

Parameter	Value
Index	1
Source IP Group	2
Destination IP Group	1
Destination Username Prefix	* (asterisk sign)

Figure 3-31: Configuring IP-to-IP Outbound Manipulation Rule – Rule Tab

Rule	Action
Index	1
Manipulation Name	remove country code
Additional Manipulation	No
Source IP Group ID	2
Destination IP Group ID	1
Source Username Prefix	*
Source Host	*
Destination Username Prefix	*
Destination Host	*
Calling Name Prefix	*
Message Condition	None
Request Type	All
ReRoute IP Group ID	-1
Call Trigger	Any
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

4. Click the **Action** tab, and then configure the parameters as follows:

Parameter	Value
Manipulated Item	Destination URI
Remove from Left	3

Figure 3-32: Configuring IP-to-IP Outbound Manipulation Rule - Action Tab

Rule	Action
Index	<input type="text" value="1"/>
Manipulated Item	Destination URI ▼
Remove From Left	<input type="text" value="3"/>
Remove From Right	<input type="text" value="0"/>
Leave From Right	<input type="text" value="255"/>
Prefix to Add	<input type="text"/>
Suffix to Add	<input type="text"/>
Privacy Restriction Mode	Transparent ▼
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

5. Click **Submit.**

The figure below shows an example of configured IP-to-IP outbound manipulation rule for calls between IP Group 2 (i.e., Genesys Contact Center) and IP Group 1 (i.e., Colt SIP Trunk):

Figure 3-33: Example of Configured IP-to-IP Outbound Manipulation Rules

IP to IP Outbound Manipulation												
Add +		Insert +		Edit ↗		Delete 🗑		Up ↑		Down ↓		Show/Hide 📄
Index ↕	Manipulation Name	Additional Manipulation	Source IP Group ID	Destination IP Group ID	Source Username Prefix	Source Host	Destination Username Prefix	Destination Host	Request Type	Manipulated Item	Prefix to Add	Suffix to Add
1	remove country code	No	2	1	*	*	*	*	All	Destination URI		

Rule Index	Description
1	Calls from IP Group 2 to IP Group 1 with any destination number (*), remove first 3 digits (country code) of the destination number.

3.10 Step 10: Remote Agents

This section describes the SBC configuration for Remote User Agents. Remote Agent DNs are registered on the SBC or through the SBC to the Genesys SIP Server. In the the Interoperability testing scenario, the Remote Agents are configured on a new Signaling Routing Domain over an existing untrusted interface.


3.10.1 Step 10a: Configure Media Realm for Remote Agent

Remote Agents interact with the SBC over the Untrusted interface. Use the Media Realm table to designate the media port range that will be associated with the Remote Agents.

➤ **To configure the Media Realm for remote agent:**

1. Open the **Advanced Parameters** page (**Configuration** tab > **VoIP** menu > **Media Realm Table**).


Figure 3-34: Configuring Remote Agent Media Realm



Edit Record #3	
Index	3
Media Realm Name	MR3-RemoteAgents
IPv4 Interface Name	Untrusted
IPv6 Interface Name	None
Port Range Start	9000
Number Of Media Session Legs	100
Port Range End	9990
Default Media Realm	No
QoE Profile	None
BW Profile	None
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

The figure below shows an example of a configured Media Realm Table including the Media Realm for Remote Agents.

Figure 3-35: Configuring Remote Agent Media Realm



Index	Media Realm Name	IPv4 Interface Name	IPv6 Interface Name
1	MR1-SBC2Genesys	Trusted	None
2	MR2-SBC2Colt	Untrusted	None
3	MR3-RemoteAgents	Untrusted	None

3.10.2 Step 10b: Configure SRD for Remote Agent

This step shows how to create a new SRD for the Remote Agents.

➤ **To configure the SRD for remote agent:**

1. Open the SRD Settings page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **SRD Table**).
2. Configure an SRD for the SBC's internal interface (toward Genesys Contact Center):

Parameter	Value
SRD Index	3
SRD Name	SRD3-RemoteAgents (descriptive name for SRD)
Media Realm	MR3-RemoteAgents (associates SRD with Media Realm)

Figure 3-36: Configuring SRD for Remote Agents

Edit Record #3	
Index	3
Name	SRD3-RemoteAgents
Media Realm Name	MR3-RemoteAgents
Media Anchoring	Enable
Block Unregistered Users	NO
Max. Number of Registered Users	-1
Enable Un-Authenticated Registrations	Enable
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

The figure below shows an example of configured SRD Table including the Media Realm for Remote Agents.

Figure 3-37: Configuring Remote Agent Media Realm

SRD Table			
<input type="button" value="Add +"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/>			<input type="button" value="Show/Hide"/>
Index	Name	Media Realm Name	Media Anchoring
1	SRD1-Genesys	MR1-SBC2Genesys	Enable
2	SRD2-Colt	MR2-SBC2Colt	Enable
3	SRD3-RemoteAgents	MR3-RemoteAgents	Enable

3.10.3 Step 10c: Configure SIP Signaling Interfaces for Remote Agent

Create a new SIP Signaling interface on the Untrusted Network Interface for the Remote Agents.


➤ To configure SIP Interfaces for remote agent:

1. Open the SIP Interface Table page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **SIP Interface Table**).
2. Configure a SIP interface for the LAN:

Parameter	Value
Index	3
Interface Name	RemoteAgents (arbitrary descriptive name)
Network Interface	Untrusted
Application Type	SBC
TCP and UDP	5070
TLS Port	5070
SRD	3

The configured SIP Interfaces Table, including the Remote Agents, are shown in the figure below:

Figure 3-38: Configured SIP Interfaces for Remote Agents in SIP Interface Table



SIP Interface Table							
Add +		Edit ✎		Delete 🗑		Show/Hide 📄	
Index ↕	SIP Interface Name	Network Interface	Application Type	UDP Port	TCP Port	TLS Port	SRD
1	Genesys	Trusted	SBC	5060	5060	5061	1
2	Colt	Untrusted	SBC	5060	5060	5061	2
3	RemoteAgents	Untrusted	SBC	5070	5070	5071	3

3.10.4 Step 10d: Configure Remote (User) Agents IP Group

In the interoperability test topology, an IP User Group was configured for Remote (User) Agents registering from the WAN.

➤ **To configure an IP User Group:**

1. Open the IP Group Table page (**Configuration** tab > **VoIP** menu > **VoIP Network** > **IP Group Table**).
2. Configure an IP Group for the Remote Agents as follows:

Parameter	Value
Index	3
Type	User
Description	Remote Agents (arbitrary descriptive name)
SRD	1
Media Realm Name	MR3-RemoteAgents
IP Profile ID	3

Figure 3-39: Configuring an IP Group for the Remote (User) Agents (Common Tab)

Common SBC	
Index	3
Type	User
Description	Remote Agents
Proxy Set ID	-1
SIP Group Name	
Contact User	
SRD	3
Media Realm Name	MR3-RemoteAgents
IP Profile ID	3
Local Host Name	
UUI Format	Disable
QoE Profile	None
Bandwidth Profile	None
Media Enhancement Profile	None
Always Use Source Address	No

Figure 3-40: Configuring an IP Group for the Genesys Call Center (SBC Tab)

Common	SBC
Index	3
Classify By Proxy Set	Disable
Max. Number of Registered Users	-1
Inbound Message Manipulation Set	-1
Outbound Message Manipulation Set	-1
Registration Mode	User Initiates Registrat
Authentication Mode	User Authenticates
Authentication Method List	
SBC Client Forking Mode	Sequential
Source URI Input	
Destination URI Input	
Username	
Password	
Msg Man User Defined String1	
Msg Man User Defined String2	
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

The configured IP Groups are shown in the figure below:

Figure 3-41: Configured IP Group for Remote Users in IP Group Table

IP Group Table					
<input type="button" value="Add +"/> <input type="button" value="Edit ✎"/> <input type="button" value="Delete 🗑"/>			<input type="button" value="Show/Hide 📄"/>		
Index ↕	Type	Description	Proxy Set ID	SIP Group Name	Contact User
1	Server	IPG1-SBC2Genesys	1	sipserver.genesys-iot.com	
2	Server	IPG2-SBC2Colt	2	gw0.colt-iot.com	
3	User	Remote Agents	-1		

3.10.5 Step 10e: Configure IP Profiles for Remote Agents

This step describes how to configure IP Profiles for the Remote (User) Agents.



Note: The IP Profile index values were assigned to the IP Groups in the previous step (see Section 3.5 on page 26).

➤ **To configure IP Profile for the Remote (User) Agent:**

1. Open the IP Profile Settings page (**Configuration** tab > **VoIP** > **Coders and Profiles** > **IP Profile Settings**).
2. Click **Add**.
3. Click the **Common** tab, and then configure the parameters as follows:

Parameter	Value
Index	3
Profile Name	Remote Users (arbitrary descriptive name)

Figure 3-42: Configuring IP Profile for Remote Users (Common Tab)

Parameter	Value
Index	3
Profile Name	Remote Users
RTP IP DiffServ	46
Signaling DiffServ	40
RTP Redundancy Depth	0
Disconnect on Broken Connection	Yes
Media IP Version Preference	Only IPv4
Symmetric MKI	Disable
MKI Size	0
Reset SRTP Upon Re-key	Disable
Generate SRTP keys mode	Only If Required



Note: Presently, no parameters require configuration on the **SBC** tab for the Genesys Contact Center IP Profile. All parameters are set to their default values. The IP Profile is created for the purpose of future configuration only.

Figure 3-43: Configuring IP Profile for Remote (User) Agents (SBC Tab)

Common		SBC
Index	3	
Extension Coders Group ID	None	
Transcoding Mode	Only If Required	
Allowed Media Types		
Allowed Coders Group ID	None	
Allowed Video Coders Group ID	None	
Allowed Coders Mode	Restriction	
SBC Media Security Behavior	As Is	
RFC 2833 Behavior	As Is	
Alternative DTMF Method	As Is	
P-Asserted-Identity	As Is	
Diversion Mode	As Is	
History-Info Mode	As Is	
Fax Coders Group ID	None	
Fax Behavior	As Is	
Fax Offer Mode	All coders	
Fax Answer Mode	Single coder	
PRACK Mode	Transparent	
Session Expires Mode	Transparent	
Remote Update Support	Supported	
Remote re-INVITE	Supported	
Remote Delayed Offer Support	Supported	
Remote REFER Behavior	Regular	
Remote 3xx Behavior	Transparent	
Remote Multiple 18x	Supported	
Remote Early Media Response Type	Transparent	
Remote Early Media	Supported	
Enforce MKI Size	Don't enforce	
Remote Early Media RTP Behavior	Immediate	
Remote RFC 3960 Gateway Model Support	Not Supported	
Remote Can Play Ringback	Yes	
RFC 2833 DTMF Payload Type	0	
User Registration Time	0	
Reliable Held Tone Source	Yes	
Play Held Tone	No	
Remote Hold Format	Transparent	
Remote Replaces Behavior	Transparent	
SDP Ptime Answer	Remote Answer	
Preferred PTime	0	
Use Silence Suppression	Transparent	
RTP Redundancy Behavior	AS IS	
Play RBT To Transferee	No	
RTCP Mode	Transparent	
RTCP Mode	Transparent	
Jitter Compensation	Disable	
Remote Renegotiate on Fax Detection	Don't Care	

Figure 3-44: Configured IP Profiles in IP Profile Table

IP Profile Settings	
<div> Add + Edit ✎ Delete 🗑️ </div> <div>Show/Hide 📄</div>	
Index	Profile Name
1	Genesys SIP Server
2	Colt
3	Remote Users

3.10.6 Step 10f: Configure Classification Table for Remote Agents

The Classification rules classify incoming SIP dialog-initiating requests to an IP Group from where the SIP dialog request was received. The identified IP Group is then used in the manipulation and routing processes. For Remote Users arriving on an interface with multiple IP Groups, the classification rules will determine the origination IP Group.

➤ **To configure IP Profile for the Remote (User) Agent:**

1. Open the Classification Table page (**Configuration** tab > **VoIP** > **SBC** > **Routing** > **SBC** > **Classification Table**).
2. Click **Add**.
3. On the **Rule** tab, configure the parameters as follows:

Parameter	Value
Index	1
Profile Name	Remote Users (arbitrary descriptive name)
Source SRD ID	3


Figure 3-45: Configuring Rule Tab of the Classification Table

Rule	Action
Index	1
Classification Name	Remote Users
Message Condition	None
Source SRD ID	3
Source IP Address	
Source Port	0
Source Transport Type	Any
Source Username Prefix	*
Source Host	*
Destination Username Prefix	*
Destination Host	*
<div> <input checked="" type="button" value="Submit"/> <input type="button" value="Cancel"/> </div>	

4. On the **Action** tab, configure the parameters as follows:

Parameter	Value
Source SRD ID	3

Figure 3-46: Configured IP Profiles in IP Profile Table



The configured IP Remote Agent Groups are shown in the figure below:

Figure 3-47: Configured Classification Rule for Remote (Users) Agents

Classification Table								
Add + Edit ✎ Delete 🗑 Up ↑ Down ↓			Show/Hide 📄					
Index	Classification Name	Message Condition	Source SRD ID	Source IP Address	Source Port	Source Username Prefix	Destination Host	Action Type
1	Remote Users	None	3		0	*	*	Allow

3.10.7 Step 10g: Configure IP-to-IP Call Routing Rules for Remote (User) Agent

The following IP-to-IP call routing rules were configured (see Section 3.8 on page 37):

- Terminate SIP OPTIONS messages on the SBC that are received from the LAN
- Calls from Genesys Contact Center to Colt SIP Trunk
- Calls from Colt SIP Trunk to Genesys Contact Center

This step shows how to configure additional IP-to-IP call routing rules that are required for routing calls between the Remote Users (classified to a particular IP Group via the Classification table in Section 3.10.6) and the Genesys SIP Server.

For the interoperability test topology, IP-to-IP routing rules were configured to route SIP messages between the Remote (User) Agents and the Genesys SIP Server, and to ensure that the messages are routed back to the correct user group to reach the intended agent.

➤ **To configure IP-to-IP routing rules:**

1. Open the IP-to-IP Routing Table page (**Configuration** tab > **VoIP** menu > **SBC** > **Routing SBC** > **IP-to-IP Routing Table**).
2. Configure a rule to terminate SIP OPTIONS messages received from the LAN:
 - a. Click **Add**.
 - b. Click the **Rule** tab, and then configure the parameters as follows:

Parameter	Value
Index	3
Route Name	RemoteAgents2Genesys (arbitrary descriptive name)
Source IP Group ID	3

Figure 3-48: Configuring IP-to-IP Routing Rule for Terminating RemoteAgents2Genesys – Rule Tab

Rule	Action
Index	3
Route Name	RemoteAgents2Genesys
Source IP Group ID	3
Source Username Prefix	*
Source Host	*
Destination Username Prefix	*
Destination Host	*
Request Type	All
Message Condition	None
ReRoute IP Group ID	-1
Call Trigger	Any
Call Setup Rules Set ID	-1
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

- Click the **Action** tab, configure the parameters as follows, and then click **Submit**.

Parameter	Value
Destination Type	IP Group
Destination IP Group ID	1
Destination SRD	1

Figure 3-49: Configuring IP-to-IP Routing Rule for Terminating RemoteAgents2Genesys – Action Tab

Rule	Action
Index	3
Destination Type	IP Group
Destination IP Group ID	1
Destination SRD ID	1
Destination Address	
Destination Port	0
Destination Transport Type	
Alternative Route Options	Route Row
Group Policy	None
Cost Group	None
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

4. Configure a rule to route calls from the Genesys Contact Center to the Remote User Agent Group. Note in this case, the rule is inserted in the IP-to-IP Routing table above the routing rule that already exists for calls from IP Group 1 (Genesys) toward the Colt ITSP IP Group 2. For the Genesys to Remote Agent routing rule, the destination number is used to differentiate these calls from those calls that will be routed to the Colt ITSP. For calls in the Remote Agent group, the SBC will determine the next destination from the AOR.
 - a. Select Index 1 (Genesys2Colt route), and then click **Insert +**.
 - b. Click the **Rule** tab, configure the parameters as follows, and then click **Submit**.

Parameter	Value
Index	1
Route Name	Genesys2RemoteAgents (arbitrary descriptive name)
Source IP Group ID	1
Destination Username Prefix	207*0053 (block of number allocated to remote agents)

Figure 3-50: Configuring IP-to-IP Routing Rule for Genesys to Remote Agent Group – Rule tab

Rule	Action
Index	1
Route Name	Genesys2RemoteAgents
Source IP Group ID	1
Source Username Prefix	*
Source Host	*
Destination Username Prefix	207*0053
Destination Host	*
Request Type	All
Message Condition	None
ReRoute IP Group ID	-1
Call Trigger	Any
Call Setup Rules Set ID	-1
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

- Click the **Action** tab, and then configure the parameters as follows:

Parameter	Value
Destination Type	IP Group
Destination IP Group ID	3
Destination SRD ID	3

Figure 3-51: Configuring IP-to-IP Routing Rule for Genesys to Colt – Action tab

Rule	Action
Index	1
Destination Type	IP Group
Destination IP Group ID	3
Destination SRD ID	3
Destination Address	
Destination Port	0
Destination Transport Type	
Alternative Route Options	Route Row
Group Policy	None
Cost Group	None
<input type="button" value="Submit"/> <input type="button" value="Cancel"/>	

The configured IP-to-IP routing rules including rules for Remote Agents are shown in the figure below:

Figure 3-52: Configured IP-to-IP Routing Rules in IP-to-IP Routing Table

IP-to-IP Routing Table										
<input type="button" value="Add +"/> <input type="button" value="Insert +"/> <input type="button" value="Edit"/> <input type="button" value="Delete"/> <input type="button" value="Up ↑"/> <input type="button" value="Down ↓"/> <input type="button" value="Show/Hide"/>										
Index	Route Name	Source Host	Destination Username Prefix	Destination Host	Message Condition	ReRoute IP Group ID	Call Trigger	Call Setup Rules Set ID	Destination Type	Destination SRD ID
0	OPTIONS termination	*	*	*	None	-1	Any	-1	Dest Address	None
1	Genesys2RemoteAgents	*	207*0053	*	None	-1	Any	-1	IP Group	3
2	Genesys2Colt	*	*	*	None	-1	Any	-1	IP Group	2
3	Colt2Genesys	*	*	*	None	-1	Any	-1	IP Group	1
4	RemoteAgents2Genesys	*	*	*	None	-1	Any	-1	IP Group	1

Page 1 of 1 Show 10 records per page View 1 - 5 of 5



Note: The routing configuration may change according to your specific deployment topology. For example, the deployment specification may indicate a particular set of numbers that should be routed to the User group; however, a particular deployment may handle the routing of Remote Agents over a different trunk from the Genesys SIP Server or may require the use of other criteria/filters in the routing table.


3.11 Step 11: Reset the SBC

After completing the configuration of the SBC as described in this chapter, save ("burn") the configuration to the SBC's flash memory with a reset for the settings to take effect.

➤ **To save the configuration to flash memory:**

1. Open the Maintenance Actions page (**Maintenance** tab > **Maintenance** menu > **Maintenance Actions**).

Figure 3-53: Resetting the SBC



▼ Reset Configuration	
Reset Board	<input type="button" value="Reset"/>
Burn To FLASH	Yes ▼
Graceful Option	No ▼
▼ LOCK / UNLOCK	
Lock	<input type="button" value="LOCK"/>
Graceful Option	No ▼
Gateway Operational State	UNLOCKED
▼ Save Configuration	
Burn To FLASH	<input type="button" value="BURN"/>

2. Make sure that the 'Burn to FLASH' field is set to **Yes** (default).
3. Click the **Reset** button.

A AudioCodes *ini* File

This appendix shows the *ini* configuration file of the SBC, corresponding to the Web-based configuration described in Section 3 on page 13.



Note: To load and save an *ini* file, use the Configuration File page (**Maintenance** tab > **Software Update** menu > **Configuration File**).

```
;*****
;** Ini File **
;*****

;Board: Mediant SW
;Board Type: 73
;Serial Number: 115991455101440
;Product Key:
;Slot Number: 1
;Software Version: 6.80A.216.008
;DSP Software Version: SOFTDSP => 660.01
;Board IP Address: 192.168.20.200
;Board Subnet Mask: 255.255.255.0
;Board Default Gateway: 192.168.20.1
;Ram size: 7832M   Flash size: 0M
;Num of DSP Cores: 0   Num DSP Channels: 0
;Profile: NONE
;Key features:;Board Type: Mediant SW ;Max SW Ver: 9.80;QOE features:
VoiceQualityMonitoring MediaEnhancement ;Coders: G723 G729 G728 NETCODER
GSM-FR GSM-EFR AMR EVRC-QCELP G727 ILBC EVRC-B AMR-WB G722 EG711 ;DSP
Voice features: RTCP-XR ;Security: IPSEC MediaEncryption
EncryptControlProtocol ;Channel Type: DspCh=2000 IPMediaDspCh=2000 ;HA
;Control Protocols: FEU=500 MGCP MEGACO H323 SIP SASurvivability SBC=1000
;Default features:;Coders: G711 G726;

;MAC Addresses in use:
;-----
;GROUP_1 - 6c:3b:e5:51:49:68
;GROUP_2 - 6c:3b:e5:51:49:69
;GROUP_3 - e4:11:5b:97:52:06
;GROUP_4 - e4:11:5b:97:52:07
;-----

[SYSTEM Params]

;VpFileLastUpdateTime is hidden but has non-default value
NTPServerIP = '0.0.0.0'
;PM_gwINVITEDialogs is hidden but has non-default value
;PM_gwSUBSCRIBEDialogs is hidden but has non-default value
;PM_gwSBCRegisteredUsers is hidden but has non-default value
```

[BSP Params]

```
PCMLawSelect = 3
EnableLANWatchdog = 0
AuthorizedTPNCPServers_0 = 0.0.0.0
AuthorizedTPNCPServers_1 = 0.0.0.0
AuthorizedTPNCPServers_2 = 0.0.0.0
AuthorizedTPNCPServers_3 = 78.75.78.85
RoutingTableHopsCountColumn = 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,
1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,
1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,
1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,
1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,
0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0,
0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0,
0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0,
0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0,
0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0
UdpPortSpacing = 10
EnterCpuOverloadPercent = 99
ExitCpuOverloadPercent = 95
```

[ControlProtocols Params]

```
AdminStateLockControl = 0
```

[MGCP Params]

[MEGACO Params]

```
EP_Num_0 = 0
EP_Num_1 = 1
EP_Num_2 = 1
EP_Num_3 = 0
EP_Num_4 = 0
```

[Voice Engine Params]

```
BrokenConnectionEventTimeout = 100
FarEndDisconnectSilenceMethod = 1
FarEndDisconnectSilencePeriod = 120
```

[WEB Params]

```
LogoWidth = '145'
;HTTPSPkeyFileName is hidden but has non-default value
;HTTPSCertFileName is hidden but has non-default value
```

[SIP Params]

```
;ISPRACKREQUIRED is hidden but has non-default value
PROGRESSINDICATOR2IP = -1
```

```
CDRSYSLOGSERVERIP = 0.0.0.0
PSTNALERTTIMEOUT = 180
EmergencyNumbers = '', '', '', ''
SBCREGISTRATIONTIME = 0
ENABLESBCCAPPLICATION = 1
MSLDAPPRIMARYKEY = 'telephoneNumber'
SESSIONEXPIRESDISCONNECTTIME = 32
ENERGYDETECTORCMD = 104
ANSWERDETECTORCMD = 12582952

[IPsec Params]

[SNMP Params]

[ PhysicalPortsTable ]

FORMAT PhysicalPortsTable_Index = PhysicalPortsTable_Port,
PhysicalPortsTable_Mode, PhysicalPortsTable_NativeVlan,
PhysicalPortsTable_SpeedDuplex, PhysicalPortsTable_PortDescription,
PhysicalPortsTable_GroupMember, PhysicalPortsTable_GroupStatus;
PhysicalPortsTable 0 = "GE_1", 1, 1, 4, "Trusted", "GROUP_1", "Active";
PhysicalPortsTable 1 = "GE_2", 1, 2, 4, "Untrusted", "GROUP_2", "Active";
PhysicalPortsTable 2 = "GE_3", 1, 3, 4, "User Port #2", "GROUP_3",
"Active";
PhysicalPortsTable 3 = "GE_4", 1, 4, 4, "User Port #3", "GROUP_4",
"Active";

[ \PhysicalPortsTable ]

[ EtherGroupTable ]

FORMAT EtherGroupTable_Index = EtherGroupTable_Group,
EtherGroupTable_Mode, EtherGroupTable_Member1, EtherGroupTable_Member2;
EtherGroupTable 0 = "GROUP_1", 1, "GE_1", "";
EtherGroupTable 1 = "GROUP_2", 1, "GE_2", "";
EtherGroupTable 2 = "GROUP_3", 1, "GE_3", "";
EtherGroupTable 3 = "GROUP_4", 1, "GE_4", "";

[ \EtherGroupTable ]

[ DeviceTable ]

FORMAT DeviceTable_Index = DeviceTable_VlanID,
DeviceTable_UnderlyingInterface, DeviceTable_DeviceName;
DeviceTable 0 = 1, "GROUP_1", "GROUP_1";
DeviceTable 1 = 2, "GROUP_2", "GROUP_2";
DeviceTable 2 = 3, "GROUP_3", "GROUP_3";
DeviceTable 3 = 4, "GROUP_4", "GROUP_4";
```

```
[ \DeviceTable ]
```

```
[ InterfaceTable ]
```

```
FORMAT InterfaceTable_Index = InterfaceTable_ApplicationTypes,  
InterfaceTable_InterfaceMode, InterfaceTable_IPAddress,  
InterfaceTable_PrefixLength, InterfaceTable_Gateway,  
InterfaceTable_VlanID, InterfaceTable_InterfaceName,  
InterfaceTable_PrimaryDNSServerIPAddress,  
InterfaceTable_SecondaryDNSServerIPAddress,  
InterfaceTable_UnderlyingDevice;  
InterfaceTable 0 = 6, 10, 192.168.20.200, 24, 192.168.20.1, 1, "Trusted",  
0.0.0.0, 0.0.0.0, "GROUP_1";  
InterfaceTable 1 = 5, 10, 203.0.113.120, 26, 203.0.113.65, 2,  
"Untrusted", 8.8.4.4, 8.8.8.8, "GROUP_2";
```

```
[ \InterfaceTable ]
```

```
[ DspTemplates ]
```

```
FORMAT DspTemplates_Index = DspTemplates_DspTemplateName,  
DspTemplates_DspResourcesPercentage;  
DspTemplates 0 = 0, 100;
```

```
[ \DspTemplates ]
```

```
[ CpMediaRealm ]
```

```
FORMAT CpMediaRealm_Index = CpMediaRealm_MediaRealmName,  
CpMediaRealm_IPv4IF, CpMediaRealm_IPv6IF, CpMediaRealm_PortRangeStart,  
CpMediaRealm_MediaSessionLeg, CpMediaRealm_PortRangeEnd,  
CpMediaRealm_IsDefault, CpMediaRealm_QoeProfile, CpMediaRealm_BWProfile;  
CpMediaRealm 1 = "MR1-SBC2Genesys", "Trusted", "", 6000, 100, 6990, 1,  
"", "";  
CpMediaRealm 2 = "MR2-SBC2Colt", "Untrusted", "", 8000, 100, 8990, 0, "",  
"";  
CpMediaRealm 3 = "MR3-RemoteAgents", "Untrusted", "", 9000, 100, 9990, 0,  
"", "";
```

```
[ \CpMediaRealm ]
```

```
[ SRD ]
```

```
FORMAT SRD_Index = SRD_Name, SRD_MediaRealm, SRD_IntraSRDMediaAnchoring,  
SRD_BlockUnRegUsers, SRD_MaxNumOfRegUsers,  
SRD_EnableUnAuthenticatedRegistrations;  
SRD 1 = "SRD1-Genesys", "MR1-SBC2Genesys", 0, 0, -1, 1;  
SRD 2 = "SRD2-Colt", "MR2-SBC2Colt", 0, 0, -1, 1;  
SRD 3 = "SRD3-RemoteAgents", "MR3-RemoteAgents", 0, 0, -1, 1;
```



```
[ \SRD ]
```

```
[ ProxyIp ]
```

```
FORMAT ProxyIp_Index = ProxyIp_IpAddress, ProxyIp_TransportType,  
ProxyIp_ProxySetId;  
ProxyIp 0 = "sipserver.genesys-iot.com:5060", -1, 1;  
ProxyIp 1 = "gw0.colts-iot.com:5060", -1, 2;
```

```
[ \ProxyIp ]
```

```
[ IpProfile ]
```

```
; ** NOTE: Changes were made to active configuration.  
; **      The data below is different from current values.  
FORMAT IpProfile_Index = IpProfile_ProfileName, IpProfile_IpPreference,  
IpProfile_CodersGroupID, IpProfile_IsFaxUsed,  
IpProfile_JitterBufMinDelay, IpProfile_JitterBufOptFactor,  
IpProfile_IPDiffServ, IpProfile_SigIPDiffServ, IpProfile_SCE,  
IpProfile_RTPRedundancyDepth, IpProfile_RemoteBaseUDPPort,  
IpProfile_CNGmode, IpProfile_VxxTransportType, IpProfile_NSEMode,  
IpProfile_IsDTMFUsed, IpProfile_PlayRBTone2IP,  
IpProfile_EnableEarlyMedia, IpProfile_ProgressIndicator2IP,  
IpProfile_EnableEchoCanceller, IpProfile_CopyDest2RedirectNumber,  
IpProfile_MediaSecurityBehaviour, IpProfile_CallLimit,  
IpProfile_DisconnectOnBrokenConnection, IpProfile_FirstTxDtmfOption,  
IpProfile_SecondTxDtmfOption, IpProfile_RxDTMFOption,  
IpProfile_EnableHold, IpProfile_InputGain, IpProfile_VoiceVolume,  
IpProfile_AddIEInSetup, IpProfile_SBCExtensionCodersGroupID,  
IpProfile_MediaIPVersionPreference, IpProfile_TranscodingMode,  
IpProfile_SBCAllowedMediaTypes, IpProfile_SBCAllowedCodersGroupID,  
IpProfile_SBCAllowedVideoCodersGroupID, IpProfile_SBCAllowedCodersMode,  
IpProfile_SBCMediaSecurityBehaviour, IpProfile_SBCRFC2833Behavior,  
IpProfile_SBCAlternativeDTMFMethod, IpProfile_SBCAssertIdentity,  
IpProfile_AMDSensitivityParameterSuit, IpProfile_AMDSensitivityLevel,  
IpProfile_AMDMaxGreetingTime, IpProfile_AMDMaxPostSilenceGreetingTime,  
IpProfile_SBCDiversificationMode, IpProfile_SBCHistoryInfoMode,  
IpProfile_EnableQSIGTunneling, IpProfile_SBCFaxCodersGroupID,  
IpProfile_SBCFaxBehavior, IpProfile_SBCFaxOfferMode,  
IpProfile_SBCFaxAnswerMode, IpProfile_SbcPrackMode,  
IpProfile_SBCSessionExpiresMode, IpProfile_SBCRemoteUpdateSupport,  
IpProfile_SBCRemoteReinviteSupport,  
IpProfile_SBCRemoteDelayedOfferSupport, IpProfile_SBCRemoteReferBehavior,  
IpProfile_SBCRemote3xxBehavior, IpProfile_SBCRemoteMultiple18xSupport,  
IpProfile_SBCRemoteEarlyMediaResponseType,  
IpProfile_SBCRemoteEarlyMediaSupport, IpProfile_EnableSymmetricMKI,  
IpProfile_MKISize, IpProfile_SBCEnforceMKISize,  
IpProfile_SBCRemoteEarlyMediaRTP, IpProfile_SBCRemoteSupportsRFC3960,  
IpProfile_SBCRemoteCanPlayRingback, IpProfile_EnableEarly183,  
IpProfile_EarlyAnswerTimeout, IpProfile_SBC2833DTMFPayloadType,  
IpProfile_SBCUserRegistrationTime, IpProfile_ResetSRTPStateUponRekey,  
IpProfile_AmdMode, IpProfile_SBCReliableHeldToneSource,  
IpProfile_GenerateSRTPKeys, IpProfile_SBCPlayHeldTone,  
IpProfile_SBCRemoteHoldFormat, IpProfile_SBCRemoteReplacesBehavior,  
IpProfile_SBCSDPPTIMEAnswer, IpProfile_SBCPreferredPTIME,  
IpProfile_SBCUseSilenceSupp, IpProfile_SBCRTPRedundancyBehavior,
```

```
IpProfile_SBCPlayRBTToTransferee, IpProfile_SBCRTCPMode,
IpProfile_SBCJitterCompensation,
IpProfile_SBCRemoteRenegotiateOnFaxDetection,
IpProfile_JitterBufMaxDelay;
IpProfile 1 = "Genesys SIP Server", 1, 0, 0, 10, 10, 46, 40, 0, 0, 0, 0, 0,
2, 0, 0, 0, 0, -1, 1, 0, 0, -1, 1, 4, -1, 1, 1, 0, 0, "", -1, 0, 0, "", -
1, -1, 0, 0, 0, 0, 0, 0, 8, 300, 400, 0, 0, 0, -1, 0, 0, 1, 3, 0, 2, 2,
1, 0, 0, 1, 0, 1, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0,
0, 0, 0, 0, 0, 0, 0, 300;
IpProfile 2 = "Colt", 1, 0, 0, 10, 10, 46, 40, 0, 0, 0, 0, 2, 0, 0, 0, 0,
-1, 1, 0, 0, -1, 1, 4, -1, 1, 1, 0, 0, "", -1, 0, 0, "", -1, -1, 0, 0, 0,
0, 0, 0, 8, 300, 400, 0, 0, 0, -1, 0, 0, 1, 3, 0, 2, 2, 1, 2, 0, 1, 0, 1,
0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0,
0, 300;
IpProfile 3 = "Remote Users", 1, 0, 0, 10, 10, 46, 40, 0, 0, 0, 0, 2, 0,
0, 0, 0, -1, 1, 0, 0, -1, 1, 4, -1, 1, 1, 0, 0, "", -1, 0, 0, "", -1, -1,
0, 0, 0, 0, 0, 0, 8, 300, 400, 0, 0, 0, -1, 0, 0, 1, 3, 0, 2, 2, 1, 0, 0,
1, 0, 1, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0, 1, 0, 0, 0, 0, 0, 0, 0, 0,
0, 0, 0, 0, 300;
```

```
[ \IpProfile ]
```

```
[ TLSContexts ]
```

```
FORMAT TLSContexts_Index = TLSContexts_Name, TLSContexts_TLSVersion,
TLSContexts_ServerCipherString, TLSContexts_ClientCipherString,
TLSContexts_OcspEnable, TLSContexts_OcspServerPrimary,
TLSContexts_OcspServerSecondary, TLSContexts_OcspServerPort,
TLSContexts_OcspDefaultResponse;
TLSContexts 0 = "default", 0, "RC4:EXP", "ALL:!ADH", 0, 0.0.0.0, 0.0.0.0,
2560, 0;
```

```
[ \TLSContexts ]
```

```
[ ProxySet ]
```

```
FORMAT ProxySet_Index = ProxySet_ProxyName,
ProxySet_EnableProxyKeepAlive, ProxySet_ProxyKeepAliveTime,
ProxySet_ProxyLoadBalancingMethod, ProxySet_IsProxyHotSwap, ProxySet_SRD,
ProxySet_ClassificationInput, ProxySet_TLSContext,
ProxySet_ProxyRedundancyMode, ProxySet_DNSResolveMethod,
ProxySet_KeepAliveFailureResp;
ProxySet 0 = "", 0, 60, 0, 0, 0, 0, "0", -1, -1, "";
ProxySet 1 = "Genesys SIP Server", 1, 60, 0, 0, 1, 0, "", -1, -1, "";
ProxySet 2 = "Colt", 1, 60, 0, 0, 2, 0, "", -1, -1, "";
```

```
[ \ProxySet ]
```

```
[ IPGroup ]
```

```
FORMAT IPGroup_Index = IPGroup_Type, IPGroup_Description,
IPGroup_ProxySetId, IPGroup_SIPGroupName, IPGroup_ContactUser,
IPGroup_EnableSurvivability, IPGroup_ServingIPGroup,
```

```

IPGroup_SipReRoutingMode, IPGroup_AlwaysUseRouteTable,
IPGroup_RoutingMode, IPGroup_SRD, IPGroup_MediaRealm,
IPGroup_ClassifyByProxySet, IPGroup_ProfileId, IPGroup_MaxNumOfRegUsers,
IPGroup_InboundManSet, IPGroup_OutboundManSet, IPGroup_RegistrationMode,
IPGroup_AuthenticationMode, IPGroup_MethodList,
IPGroup_EnableSBCCClientForking, IPGroup_SourceUriInput,
IPGroup_DestUriInput, IPGroup_ContactName, IPGroup_Username,
IPGroup_Password, IPGroup_UIFormat, IPGroup_QOEProfile,
IPGroup_BWProfile, IPGroup_MediaEnhancementProfile,
IPGroup_AlwaysUseSourceAddr, IPGroup_MsgManUserDef1,
IPGroup_MsgManUserDef2;
IPGroup 1 = 0, "IPG1-SBC2Genesys", 1, "sipserver.genesys-iot.com", "", 0,
-1, -1, 0, -1, 1, "MR1-SBC2Genesys", 1, 1, -1, -1, -1, 0, 0, "", 0, -1, -
1, "192.168.20.200", "", "$1$gQ==", 0, "", "", "", 0, "", "";
IPGroup 2 = 0, "IPG2-SBC2Colt", 2, "gw0.colt-iot.com", "", 0, -1, -1, 0,
-1, 2, "MR2-SBC2Colt", 1, 2, -1, -1, -1, 0, 0, "", 0, -1, -1, "", "",
"$1$gQ==", 0, "", "", "", 0, "", "";
IPGroup 3 = 1, "Remote Agents", -1, "", "", 0, -1, -1, 0, -1, 3, "MR3-
RemoteAgents", 0, 3, -1, -1, -1, 0, 0, "", 0, -1, -1, "", "", "$1$gQ==",
0, "", "", "", 0, "", "";

```

[\IPGroup]

[IP2IPRouting]

```

FORMAT IP2IPRouting_Index = IP2IPRouting_RouteName,
IP2IPRouting_SrcIPGroupID, IP2IPRouting_SrcUsernamePrefix,
IP2IPRouting_SrcHost, IP2IPRouting_DestUsernamePrefix,
IP2IPRouting_DestHost, IP2IPRouting_RequestType,
IP2IPRouting_MessageCondition, IP2IPRouting_ReRouteIPGroupID,
IP2IPRouting_Trigger, IP2IPRouting_CallSetupRulesSetId,
IP2IPRouting_DestType, IP2IPRouting_DestIPGroupID,
IP2IPRouting_DestSRDID, IP2IPRouting_DestAddress, IP2IPRouting_DestPort,
IP2IPRouting_DestTransportType, IP2IPRouting_AltRouteOptions,
IP2IPRouting_GroupPolicy, IP2IPRouting_CostGroup;
IP2IPRouting 0 = "OPTIONS termination", 1, "*", "*", "*", "*", 0, "", -1,
0, -1, 1, -1, "", "internal", 0, -1, 0, 0, "";
IP2IPRouting 1 = "Genesys2RemoteAgents", 1, "*", "*", "207*0053", "*", 0,
"", -1, 0, -1, 0, 3, "3", "", 0, -1, 0, 0, "";
IP2IPRouting 2 = "Genesys2Colt", 1, "*", "*", "*", "*", 0, "", -1, 0, -1,
0, 2, "2", "", 0, -1, 0, 0, "";
IP2IPRouting 3 = "Colt2Genesys", 2, "*", "*", "*", "*", 0, "", -1, 0, -1,
0, 1, "1", "", 0, -1, 0, 0, "";
IP2IPRouting 4 = "RemoteAgents2Genesys", 3, "*", "*", "*", "*", 0, "", -
1, 0, -1, 0, 1, "1", "", 0, -1, 0, 0, "";

```

[\IP2IPRouting]

[Classification]

```

FORMAT Classification_Index = Classification_ClassificationName,
Classification_MessageCondition, Classification_SrcSRDID,
Classification_SrcAddress, Classification_SrcPort,
Classification_SrcTransportType, Classification_SrcUsernamePrefix,
Classification_SrcHost, Classification_DestUsernamePrefix,

```

```
Classification_DestHost, Classification_ActionType,
Classification_SrcIPGroupID;
Classification 1 = "Remote Users", "", "3", "", 0, -1, "*", "*", "*",
"*, 1, "3";

[ \Classification ]

[ SIPInterface ]

FORMAT SIPInterface_Index = SIPInterface_InterfaceName,
SIPInterface_NetworkInterface, SIPInterface_ApplicationType,
SIPInterface_UDPPort, SIPInterface_TCPPort, SIPInterface_TLSPort,
SIPInterface_SRD, SIPInterface_MessagePolicy, SIPInterface_TLSContext,
SIPInterface_TLSMutualAuthentication, SIPInterface_TCPKeepaliveEnable,
SIPInterface_ClassificationFailureResponseType;
SIPInterface 1 = "Genesys", "Trusted", 2, 5060, 5060, 5061, 1, "", "", -
1, 0, 500;
SIPInterface 2 = "Colt", "Untrusted", 2, 5060, 5060, 5061, 2, "", "", -1,
0, 500;
SIPInterface 3 = "RemoteAgents", "Untrusted", 2, 5070, 5070, 5071, 3, "",
"", -1, 0, 500;

[ \SIPInterface ]

[ IPOutboundManipulation ]

FORMAT IPOutboundManipulation_Index =
IPOutboundManipulation_ManipulationName,
IPOutboundManipulation_IsAdditionalManipulation,
IPOutboundManipulation_SrcIPGroupID,
IPOutboundManipulation_DestIPGroupID,
IPOutboundManipulation_SrcUsernamePrefix, IPOutboundManipulation_SrcHost,
IPOutboundManipulation_DestUsernamePrefix,
IPOutboundManipulation_DestHost,
IPOutboundManipulation_CallingNamePrefix,
IPOutboundManipulation_MessageCondition,
IPOutboundManipulation_RequestType,
IPOutboundManipulation_ReRouteIPGroupID, IPOutboundManipulation_Trigger,
IPOutboundManipulation_ManipulatedURI,
IPOutboundManipulation_RemoveFromLeft,
IPOutboundManipulation_RemoveFromRight,
IPOutboundManipulation_LeaveFromRight, IPOutboundManipulation_Prefix2Add,
IPOutboundManipulation_Suffix2Add,
IPOutboundManipulation_PrivacyRestrictionMode;
IPOutboundManipulation 1 = "remove country code", 0, 2, 1, "*", "*", "*",
"*, "*", "", 0, -1, 0, 1, 3, 0, 255, "", "", 0;

[ \IPOutboundManipulation ]

[ CodersGroup0 ]

FORMAT CodersGroup0_Index = CodersGroup0_Name, CodersGroup0_pTime,
CodersGroup0_rate, CodersGroup0_PayloadType, CodersGroup0_Sce;
```

```
CodersGroup0 0 = "g711Alaw64k", 20, 255, -1, 0;

[ \CodersGroup0 ]


[ RoutingRuleGroups ]

FORMAT RoutingRuleGroups_Index = RoutingRuleGroups_LCREnable,
RoutingRuleGroups_LCRAverageCallLength, RoutingRuleGroups_LCRDefaultCost;
RoutingRuleGroups 0 = 0, 0, 1;

[ \RoutingRuleGroups ]


[ ResourcePriorityNetworkDomains ]

FORMAT ResourcePriorityNetworkDomains_Index =
ResourcePriorityNetworkDomains_Name,
ResourcePriorityNetworkDomains_Ip2TelInterworking;
ResourcePriorityNetworkDomains 1 = "dsn", 0;
ResourcePriorityNetworkDomains 2 = "dod", 0;
ResourcePriorityNetworkDomains 3 = "drsn", 0;
ResourcePriorityNetworkDomains 5 = "uc", 1;
ResourcePriorityNetworkDomains 7 = "cuc", 0;

[ \ResourcePriorityNetworkDomains ]
```



Configuration Note

